

WALTON LED FLOOR LAMP

SKU# 269248

Rated Voltage 100-240V~, 50/60Hz

Thank you for purchasing this quality Lucci product. To ensure correct function and safety, please read and follow all instructions carefully before assembly, installation and use. Please keep the instructions for future reference.

Warranty


- This fitting is covered by a 3 year warranty from the date of purchase. Please retain proof of purchase.
- Warranty will be void if there is any damage due to improper usage or modification to the product.
- Failure to comply with the instructions in this manual may increase the risk of damage or injury and will void warranty.

Installation requirements

- Select a suitable location for this light fitting:
 - Ensure it is on a flat and stable surface.
 - This product is suitable for indoor use only.
 - Do not place flammable material near or over the fitting.
 - Ensure the fitting is not installed in direct line of an air vent/system and is not placed in any moist or damp areas.
- Only use the supplied LED driver with this fitting.
- Take care not to pull any electrical wires during unpacking as this may damage the connection.
- Lay out all the components on a smooth surface and make sure there are no components missing before assembling. If parts are missing, return the complete product to the place of purchase for inspection or replacement.
- Check whether the fitting has been damaged during transport. Do not operate/install any product which appears damaged in any way. Return the complete product to the place of purchase for inspection, repair or replacement.
- Do not plug into the mains power socket outlet before or during assembly. Only do so after the portable lamp is fully assembled and ready to use for the first time.

Installation directions

1. Remove all packaging material from the product.
2. Adjust the rod (A) to the desired height by loosening the knob (C). Pull the power cord (D) out as you adjust to remove any slack. Fig. 1
3. Adjust the rod (A) to the desired angle by rotating the rod. Do not rotate more than the degrees shown in following diagram, as this may damage the internal wires. Fig.2
4. Secure the rod (A) by tightening the knob (C).
5. Adjust the LED head (E) to the desired angle. Do not rotate more than the degrees shown in following diagram, as this may damage the internal wires. Fig. 3
6. Insert the LED driver (F) into the mains socket outlet and ensure it is fully plugged in.
7. Turn on power to the fitting and use the dimmer switch (B) to adjust the brightness.



NOTE: When adjusting the head (E), do not adjust more than the degrees shown in above diagram, as this may damage the internal wires.

Safety tips

- Always ensure the power is OFF and the fitting has cooled down before performing any maintenance, cleaning or adjustment to the fitting.
- To avoid injury or damage to the fitting, ensure that power leads and screws are secure before connecting the power.
- Young children should be supervised to ensure that they do not play with the portable lamp.
- Handle the fitting and/or shade with care to avoid any damage or breakage.
- Select a suitable location away from liquids and hazards.
- Ensure that the fitting does not come in contact with corrosive chemicals, etc.
- To clean, wipe with a damp clean cloth. Never soak the fitting with water.

Specifications

SKU #	269248
Colour	Oil Rub Bronze
Rated Voltage	100-240V~, 50/60Hz
LED	EVERLIGHT LEDS, 7W, 3000K, 400lm
Weight	3.7kg
Dimensions	L:355mm W:160mm H:1380mm MAX